



FLUSH SILHOUETTE SWITCHES ø22 SWITCHES & PILOT LIGHTS CW SERIES



# Push-in Switches & Pilot Lights

Smart design, simple wiring



**IDEC CORPORATION** 





# All thoughts focused on the same goal

Since the late 1970s, IDEC has continued to instill and pursue "Save and Safe", as part of our corporate DNA. Along with the rapid advancement in machine intelligence and demands for environmental resistance and high reliability in recent years, we need to face societal issues such as shortage in workforce.

To solve these issues, we have set as our goals "Safe, Simple & Smart=S<sup>3</sup> (S cube)", aiming to provide society with products and services that will bring about greater innovation and lasting quality.

# Safe

Products anyone can use with safety and assurance, from a company seeking to be number one in safety

# Simple

Products appreciated by all our customers for their ease of connection regardless of experience

Smart

Products that make labor-saving and space-saving a reality




# Useful 🔤

We provide easy and user-friendly products with new technology.

# First in the industry Six different colors with a single LED


Previously, 5 different color LEDs were required but with the new illuminated unit, only a single LED is used. Only the lens needs to be replaced to change the illumination color.

The new LED reduces maintenance time, makes stock control easier, and is enviromentally friendly.



High visibility with new LED

Brighter and clearer compared to conventional LEDS



# ISO3864-4 Safety color compliant

(Corresponding colors: R (Red), Y (Yellow), G (Green), PW (Pure white))

Safety colors are defined with ISO standards. The bright and clears colors are suited for emergency situations

# Push-in

### Smart Simple

# Simple wiring for greater work efficiency

Ferrules and solid wires can be connected simply by push-in insertion, without a screwdriver. (\*1) To remove, a flat-blade screwdriver is inserted in a simple two-action process. Since wiring can be performed regardless of operators' skill level, wiring time is reduced.

\*1) When connecting stranded wire, insert the wire while holding down the pusher with a flat-blade screwdriver.



Push the wire straight in as far as it will go.


### Removing



Hold down the pusher with a flat-blade screwdriver.



Connection is completed. Pull lightly to make sure it is firmly in place.




While holding down the pusher, pull out the wire. Release the flat-blade screwdriver.

# Time saving and efficient

Push-in connections are made simple by inserting the wire, reducing wiring time by approximately 55% compared to conventional screw terminals.

[Conditions]

Push-in: Insert wire with ferrule. Screw terminals: With screw loosened, insert wire, then tighten with electric driver.



\*2) As of IDEC research (as of January 2020)

Safe

# Reliable and easy


Finger-safe structure and vibration resistance. What's more, the space-saving design means better workability in a smaller space.

#### Stays firmly in place

Since the ferrule is held in place by a spring load, the wiring remains taut and vibration resistance is improved.

#### Finger-safe structure

IP20 Finger-safe protection enables wiring to be performed without direct contact between screwdriver and conductive part.




#### Smart Simple

# Wiring procedure comparison

Work can be performed without using tools and regardless of operators' skill level.

\*1) When ferrule is used.


# Conventional screw terminal Remove Pass wire through T



igh Tighten nal screw

Check

#### Push-in terminal (\*1)



Pull lightly to confirm

Smart

# No additional tightening needed

Because screws are not used on push-in terminals, re-tightening of screws is not required.

# Product Upgrade

The superior functions of the conventional CW Series still remain while improving ease of use.

# Contact block depth reduced Smart

Saves space inside panel and enables downsizing of equipment.

## Pushbuttons

Single contact block Panel depth **36.4**mm



# Angled Connections



Angled connections make wiring easy even when switches are mounted on a panel.

Also, 24-degree inclination faced to the panel improves the fit of the wires, and contributes to downsizing of the panel and equipment.



Double contact block Panel depth 59.6mm





# 4-contact configuration available with double contact blocks

Double contact blocks

Single contact blocks



Double contact blocks available for all models including pushbuttons, illuminated pushbuttons, selector switches, and key selector switches.

# Added Value

Our aim is to create products that enable customers to experience the utmost usability.

# Test point

A test point is available to check connectivity of the wiring. Check the connectivity easily using a tester.



# Sub-Assembled Units

Sub-assembled units can be ordered for flexible use, such as sudden changes in design.



# Flush Silhouette Switches Ø22 CW Series Push-in Switches & Pilot Lights

#### Products

1000013	
Pushbuttons:	see page 10
Illuminated pushbuttons:	see page 13
Pilot lights:	see page 16
Selector Switches:	see page 18
Key Selector Switches:	see page <mark>23</mark>



• See website for details on approvals and standards.

## **Contact Ratings**

Rated Insulation Voltage	300V
Rated Thermal Current	10A

# **Rated Operating Voltage and Current by Utilization Category**

[Specification 1] (\*1)

Rated Operating Voltage (Ue)		24V	48V	50V	110V	220V	
	AC	Resistive Load (AC-12)	10A		10A	10A	6A
Rated	50/60 Hz	Inductive Load (AC-15)	10A	_	7A	5A	3A
Operating Current (le)	DC	Resistive Load (DC-12)	10A	5A	—	2.2A	1.1A
		Inductive Load (DC-13)	5A	2A	—	1.1A	0.6A

• The operational current represents the classification by making and breaking currents (IEC60947-5-1).

#### [Specification 2] (\*2)

Rated Operating Voltage (Ue)			24V	48V	50V	110V	220V
	AC	Resistive Load (AC-12)	5A	—	5A	5A	3A
Rated Operating Current	50/60 Hz	Inductive Load (AC-15)	5A	—	3.5A	2.5A	1.5A
(le)	DC	Resistive Load (DC-12)	5A	2.5A	—	1.1A	0.55A
	00	Inductive Load (DC-13)	2.5A	1A	—	0.55A	0.3A

• The operational current represents the classification by making and breaking currents (IEC60947-5-1).

• Minimum applicable load: 3V AC/DC, 5 mA (applicable range may vary with operating conditions)

\*1) See electrical life specification on page 9.

UL, c-UL rating: A300, CCC rating: A300, TUV rating: A300

#### Degree of Protection (Table 1)


Туре	IP65	IP66	IP67	UL Type 4X
Illuminated Pushbutton	Yes	No (*2)	No (*2)	No (*2)
Pilot lights	Yes	Yes	No	Yes
Pushbutton	Yes	No (*2)	No (*2)	No (*2)
Selector Switch	Yes	Yes	Yes	Yes
Key Selector Switch	Yes	Yes	No	Yes

\*2) Yes when used with rubber boot (CW9Z-D11, -D12)

#### **LED Specifications**

Rated Insula	tion Voltage	age 250V					
Rated Operating Voltage		6V AC/DC	12V AC/DC	24V AC/DC			
Operating Vo	oltage Range	6V AC/DC ±10%	12V AC/DC ±10%	24V AC/DC ±10%			
LED Module Part No.		CW-PAQ2	CW-PAQ3	CW-PAQ4			
Current	AC	16 mA	7 mA	6 mA			
Draw	DC	12 mA	6 mA	6 mA			
Life (reference value) Approx. 30,000 hours (the illuminance is reduced to 50% of the initial intensity when us				ete DC at 25°C.)			
Internal Circuit			X1 — Limited current circuit Noise protection circuit Rectifier circuit Dimmer protection circuit				

# Push-in Contact Block (HW-P)



HW-P10R (NO contact) HW-P01 (NC contact)

	Single con	tact block	Double contact block				
Contact	1N0	1NC	2N0	2NC	1NO-1NC		
Part No.	HW-P10R	HW-P01	HW-PW2R0	HW-PW02	HW-PW1R1		
	1						
Housing	Blue / Black	Purple red	Blue / Black	Purple red	Purple red / Blue		
Push Rod	Black	Red	Black	Red	Gray		
Contact No.	3-4	1-2	1st stage: 13-14 2nd stage: 23-24	1st stage: 11-12 2nd stage: 21-22	1st stage: 13-14 2nd stage: 21-22		
Weight (approx.)	8	g		16g			

# **Specifications**

Operating Temp	erature	Non-illuminated: -25 to +60°C (no freezing) LED illuminated: -25 to +55°C (no freezing)
Operating Humi	dity	45 to 85% RH (no condensation)
Storage Tempera	ature	-40 to +80°C (no freezing)
Contact Resista	nce	50 mΩ maximum (initial value)
Insulation Resis	tance	100 MΩ minimum (500V DC megger)
Overvoltage Cat	egory	II (IEC60664-1)
Impulse Withstar	id Voltage	2.5kV (IEC60664-1 / IEC60947-5-1)
Pollution Degree	;	3 (IEC60947-5-1)
Vibratian Desist		Operating extremes: 5 to 55Hz, amplitude 0.5 mm
Vibration Resist	ance	Damage limits: 30 Hz, amplitude 1.5 mm
Shock Resistan		Operating extremes: 100 m/s <sup>2</sup>
Shock Resistant	ce	Damage limits: 1000 m/s <sup>2</sup>
Mechanical Life (minimum operations)		Pushbutton/Illuminated pushbutton Momentary: 2,000,000 (single contact block) 1,000,000 (double contact block) Maintained: 250,000(single contact block) 5elector switch: 250,000 (single contact block) 100,000 (double contact block) Key selector switch: 250,000 (single contact block) Key solector switch: 250,000 (single contact block) 100,000 (double contact block)
Electrical Life (*1)	Specification 1	Single contact block: 50,000 Double contact block: 25,000
(minimum operations)	Specification 2	Single contact block: 100,000 Double contact block: 50,000
Degree of Prote	ction	Panel front: See Degree of Protection table on page 8 Terminal: IP20 (IEC 60529)
Electrical Shock	Protection	Class II (IEC61140)
Terminal Style		Push-in terminal
Bezel Material		Polyamide
Recommended Torque for Lock		1.2 N·m


**Direct Opening of Key Selector Switch** 

Applicable Type	2-position (3NC)	3-position (2NC)
Minimum Operator Angle for Direct Opening Action	90°	45°
Minimum Operator Torque for Direct Opening Action	0.2 N·m	0.3 N·m
Maximum Operator Angle	90°	45°

# Weight (Examples)

	Illuminated Pushbutton Pushbutton	: 38g (CW1L-M1P20Q4, 2 contacts) : 37g (CW1B-M1P30, 3 contacts) : 61g (CW1B-M1P33, 6 contacts)
Weight	Pilot light	: 24g (CW1P)
(approx.)	Selector Switch	: 40g (CW1S-2P30, 3 contacts)
		: 64g (CW1S-2P33, 6 contacts)
	Key Selector Switch	: 49g (CW1K-2AP30, 3 contacts)
		: 73g (CW1K-2AP33, 6 contacts)

# Mounting Hole Layout Panel Cut (IEC60947-5-1)



Note: Determine mounting centers in consideration of the operation, wiring, and testing terminals.

\*1) Switching frequency Momentary: 1800 operations/h

Maintained: 900 operations/h

(Dimensions in mm)

# Pushbuttons

Assembled




					Package Quantity: 1
Operator Style	Bezel Color	Operation	Contact Configuration	Part No. (Ordering No.)	5 Button Color Code
Round Flush			1N0	CW1B-M1P10 5	
			1NC	CW1B-M1P01 5	B (black) G (green)
	Black	Momentary	1NO-1NC	CW1B-M1P11 5	R (red)
		Womentary	2N0	CW1B-M1P20 5	Y (yellow)
			2NC	CW1B-M1P02 5	S (blue) W (white)
			3N0	CW1B-M1P30 5	<b>H</b> (11110)
<b>1</b>	Metallic	Momentary	1N0	CW4B-M1P10 5	D (block)
			1NC	CW4B-M1P01 5	B (black) G (green)
			1NO-1NC	CW4B-M1P11 5	R (red)
			2N0	CW4B-M1P20 5	Y (yellow)
-			2NC	CW4B-M1P02 5	S (blue) W (white)
			3N0	CW4B-M1P30 5	W (WINC)
Round Extended			1N0	CW1B-M2P10 5	B (black)
	Black	Momentary	1NC	CW1B-M2P01 5	G (green) R (red)
	DIACK	Momentary	1NO-1NC	CW1B-M2P11 5	Y (yellow) S (blue)
			2N0	CW1B-M2P20 5	W (white)
			1N0	CW4B-M2P10 5	B (black)
	Metallic	Momentary	1NC	CW4B-M2P01 (5)	G (green) R (red)
	WELdIIL	womentaly	1NO-1NC	CW4B-M2P11 5	Y (yellow) S (blue)
			2N0	CW4B-M2P20 5	W (white)

Pushbuttons with 1 contact block contain 2 dummy blocks. Pushbuttons with 2 contact blocks contain 1 dummy block.
For maintained pushbuttons, select from sub-assembled units.

• For other specifications, select from sub-assembled units (P11).

#### Part No. Example

Assembled and sub-assembled unit



\*For available assembled products, see table above.

Pushb	uttons	;							
Sub-Ass	embl	ed	When ordering, s	pecify the sub-	-assembled o	rdering no. See page	e 10 for available	e assembled pr	oducts.
		As	sembled	Operator u	nit 🕂		act unit ny block, connecting unit)		
			6	Ċ	)	Ø			
					<sub-assen< td=""><td>nbled&gt; Ordering No.</td><td></td><td></td><td>Package Quantity: 1</td></sub-assen<>	nbled> Ordering No.			Package Quantity: 1
Name / Shape	Operation	Contact	<reference> Assembled Part No</reference>	. Button Color	Ор	erator Unit		Contact unit	
Name / Shape	operation	Configuration	Example	Code	Name / Shap	e Part No.(Ordering No.)	Shape	Contact Configuration	Part No. (Ordering No.)
Round Flush (Black)		1N0 1NC	CW1B-M1P105 CW1B-M1P015	_	Round Flush (Black)			1N0	CW-CNP10
	Z	1NO-1NC 1NO-2NC	CW1B-M1P115 CW1B-M1P125	-				1NC	CW-CNP01
	Momentary	2N0 2NC	CW1B-M1P205 CW1B-M1P025	-		CW1B-M15-PS		1NO-1NC	CW-CNP11
(Metallic)	Ŋ	2NO-1NC 2NO-2NC	CW1B-M1P215 CW1B-M1P225	B (black)	(Metallic)			1N0-2NC	CW-CNP12
		3NO 3NC	CW1B-M1P305 CW1B-M1P035	G (green) R (red)				2N0	CW-CNP20
	1NO 1NC	CW1B-A1P105 CW1B-A1P015	Y (yellow) S (blue) W (white)	ue)			2NC	CW-CNP02	
	Maintained	1NO-1NC 1NO-2NC	CW1B-A1P115 CW1B-A1P125	-				2NO-1NC	CW-CNP21
		2N0 2NC	CW1B-A1P205 CW1B-A1P025	-		CW1B-A16-PS		2N0-2NC	CW-CNP22
		2NO-1NC 2NO-2NC	CW1B-A1P215 CW1B-A1P225	-				3N0	CW-CNP30
		3NO 3NC	CW1B-A1P305 CW1B-A1P035					3NC	CW-CNP03
Round Extended		1N0 1NC	CW1B-M2P105 CW1B-M2P015		Round Extended			1N0	CW-CNP10
(Black)	M	1NO-1NC 1NO-2NC	CW1B-M2P115 CW1B-M2P125		(Black)			1NC	CW-CNP01
	Momentary	2N0 2NC	CW1B-M2P205 CW1B-M2P025			CW1B-M25-PS		1NO-1NC	CW-CNP11
(Motollic)	V	2NO-1NC 2NO-2NC	CW1B-M2P215 CW1B-M2P225	B (black)	(Metallic)			1NO-2NC	CW-CNP12
(Metallic)		3NO 3NC	CW1B-M2P305 CW1B-M2P035	G (green) R (red)	1			2N0	CW-CNP20
		1N0 1NC	CW1B-A2P105 CW1B-A2P015	Y (yellow) S (blue) W (white)				2NC	CW-CNP02
	A	1NO-1NC 1NO-2NC	CW1B-A2P115 CW1B-A2P125					2NO-1NC	CW-CNP21
	Maintained	2N0 2NC	CW1B-A2P205 CW1B-A2P025			CW1B-A26-PS		2NO-2NC	CW-CNP22
	á	2NO-1NC 2NO-2NC	CW1B-A2P215 CW1B-A2P225					3N0	CW-CNP30
L		3NO 3NC	CW1B-A2P305 CW1B-A2P035					3NC	CW-CNP03

Color Code	Bezel Color		
1	Black		
4	Metallic		

 $\bullet$  Specify a button color code in place of 5 in the part no.


B (black), G (green), R (red), Y (yellow), S (blue), W (white)

Part No. (Ordering No.)/ mounting positions of contact units: page 30.

# **Pushbuttons Dimensions**


All dimensions in mm

## **Round Flush**




4-contacts

#### **Round Extended**



4-contacts



• See page 9 for mounting hole layout.

#### Illuminated Pushbuttons (Round Flush / Round Extended)

#### Assembled



Package Quantity: 1

Operator Style	Bezel Color	Operation	Rated Operating Voltage	Contact Configuration	Part No. (Ordering No.)	© Illumination Color Code
Round Flush			12V AC/DC	1N0	CW1L-M1P10Q36	
				1N0	CW1L-M1P10Q46	
	Black	Momentary	24V AC/DC	1NC	CW1L-M1P01Q46	
			24V A0/D0	1NO-1NC	CW1L-M1P11Q46	
				2N0	CW1L-M1P20Q46	R (red)
			12V AC/DC	1N0	CW4L-M1P10Q36	G (green)
				1N0	CW4L-M1P10Q4 6	Y (yellow)
		Momentary	24V AC/DC	1NC	CW4L-M1P01Q46	A (amber)
	Metallic			1NO-1NC	CW4L-M1P11Q46	S (blue) PW (pure white)
				2N0	CW4L-M1P20Q4 6	
			24V AC/DC	1N0	CW4L-A1P10Q4 6	]
		Maintained		1NC	CW4L-A1P01Q4 6	
		Maintaineu	24V AG/DG	1NO-1NC	CW4L-A1P11Q4 6	
				2N0	CW4L-A1P20Q4 6	
Round Extended			12V AC/DC	1N0	CW1L-M2P10Q36	
				1N0	CW1L-M2P10Q46	
	Black	Momentary	24V AC/DC	1NC	CW1L-M2P01Q46	R (red)
			24V AG/DG	1NO-1NC	CW1L-M2P11Q46	G (green)
				2N0	CW1L-M2P20Q46	Y (yellow) A (amber)
				1N0	CW4L-M2P10Q46	S (blue)
	Metallic	M	0.41/ 4.0/00	1NC	CW4L-M2P01Q46	PW (pure white)
	wetanic	Momentary	24V AC/DC	1NO-1NC	CW4L-M2P11Q4 6	
				2N0	CW4L-M2P20Q4 6	

• Specify an illumination color code in place of <sup>(6)</sup> in the part no.

• Illuminated pushbuttons are built-in with an LED unit. For maintenance LED units, see page 32.


• Illuminated pushbuttons with 1 contact block contain1 dummy block.

• Printed film can be inserted. For size details, see page 36.

• For other specifications, select from sub-assembled units (page 14).


## Part No. Example

Assembled and sub-assembled unit



## Illuminated Pushbuttons (Round Flush / Round Extended)

Sub-Assembled When ordering, specify the sub-assembled ordering no. See page 13 for available assembled products.



					<sub-assemb< th=""><th>led&gt; Ordering No.</th><th></th><th>F</th><th>ackage Quantity:</th></sub-assemb<>	led> Ordering No.		F	ackage Quantity:
Nama / Chana	Contact Contact Accompled Port No. Illumination		Ope	rator Unit	Contac	Contact Unit for illuminated units			
Name / Shape Operation	Operation	Configuration	Assembled Part No. Example	Illumination Color Code	Name / Shape	Part No. (Ordering No.)	Shape	Contact Configuration	Part No. (Ordering No.)
Round Flush		1N0	CW1L-M1P10Q46		Round Flush			110	
(Black)	2	1NC	CW1L-M1P01Q46		(Black)			1N0	CW-CNP105
	Momentary	1NO-1NC	CW1L-M1P11Q46					1NC	
	entar	2N0	CW1L-M1P20Q46			CW <sup>①</sup> L-M1 <sup>⑥</sup> -PS		INC	<b>CW-CNP01</b> (5)
	Y	2NC	CW1L-M1P02Q46	R G				110 110	
		2N0-2NC	CW1L-M1P22Q46	Y				1NO-1NC	CW-CNP11 (5)
(Metallic)		1N0	CW1L-A1P10Q46	A				0110	
	~	1NC	CW1L-A1P01Q46	©		CW①L-A1⑥-PS		2N0	CW-CNP20 (5)
	Naint	1NO-1NC	CW1L-A1P11Q46					0110	
Maintained	aine	2N0	CW1L-A1P20Q46					2NC	CW-CNP025
	đ	2NC	CW1L-A1P02Q46					2NO-2NC	
-		2NO-2NC	CW1L-A1P22Q46					2110-2110	<b>CW-CNP22</b> (5)
Round		1N0	CW1L-M2P10Q46		Round Extended (Black)	CW①L-M2⑥-PS		110	
Extended (Black)	2	1NC	CW1L-M2P01Q46				Ø	1N0	CW-CNP105
DIACK	Momentary	1NO-1NC	CW1L-M2P11Q46					1110	
	enta	2N0	CW1L-M2P20Q46	1				1NC	<b>CW-CNP01</b> (5)
	Y	2NC	CW1L-M2P02Q46	R G				110 110	
		2N0-2NC	CW1L-M2P22Q46	Y				1NO-1NC	CW-CNP11 (5)
		1N0	CW1L-A2P10Q46	A				0110	
(Metallic)	2	1NC	CW1L-A2P01Q46	S PW				2N0	CW-CNP20 (5)
	Naint	1NO-1NC	CW1L-A2P11Q46					0110	
	Maintained	2N0	CW1L-A2P20Q46			CW1L-A26-PS		2NC	CW-CNP025
	ā	2NC	CW1L-A2P02Q46						
		2N0-2NC	CW1L-A2P22Q46					2NO-2NC	<b>CW-CNP22</b> (5)

• Specify an operating voltage code in place of (5) in the part no. Select from the table below.

Operating voltage code	Operating voltage
Q2	6V AC/DC
Q3	12V AC/DC
Q4	24V AC/DC

4 Metallic  $\bullet$  Specify an illumination color code in place of 6 in the Part No.

Color Code

1

R (red), G (green), Y (yellow), A (amber), S (blue), PW (pure white) • The assembled part no. above is when the operating voltage is 24V

**Bezel Color** 

Black


AC/DC.

Part No. (Ordering No.)/ mounting positions of contact units: page 31.


# Illuminated Pushbuttons (Round Flush / Round Extended) Dimensions

dimensions in mm

## **Round Flush**




3 to 4-contacts




# **Round Extended**





• See page 9 for mounting hole layout.



### Pilot Lights (Round Flush / Round Extended)

## Assembled



					Package Quantity: 1
Operator Style		Bezel Color	Rated Operating Voltage	Part No. (Ordering No.)	(4) Illumination Color Code
Round Flush		Disel	12V AC/DC	CW1P-1PQ3④	R (red)
		Black	24V AC/DC	CW1P-1PQ4 ④	G (green) Y (yellow)
		Metallic	12V AC/DC	CW4P-1PQ3④	A (amber) S (blue)
Black bezel	Metallic bezel	Metallic	24V AC/DC	CW4P-1PQ4 ④	PW (pure white)
Round Extended		Black	12V AC/DC	CW1P-2PQ3 ④	R (red)
L		DIACK	24V AC/DC	CW1P-2PQ4 ④	G (green) Y (yellow)
		Metallic	12V AC/DC	CW4P-2PQ3 ④	A (amber) S (blue)
Black bezel	Metallic bezel	weiding	24V AC/DC	<b>CW4P-2PQ4</b> ④	PW (pure white)


 $\bullet$  Specify an illumination color code in place of in the part no.

• Pilot lights are built-in with an LED unit. For maintenance LED units, see page 32.


• Pilot lights contain 2 dummy blocks.

• Printed film can be inserted. For size details, see page 36.

• For other specifications, select from sub-assembled units (P17).



### 16 **IDEC**




 $\bullet$  Specify a bezel color in place of in the part no.

Bezel Color
Black
Metallic

• Specify an illumination color code in place of ④ in the part no. R (red), G (green), Y (yellow), A (amber), S (blue), PW (pure white)

# **Dimensions**

#### **Round Flush**



• See page 9 for mounting hole layout.


Part No. (Ordering No.)/ mounting positions of contact units: page 31

#### **Round Extended**

12.9

Locking Ring





# All dimensions in mm

## Selector Switches (Knob Operator)

# Assembled



Lever operators are available as sub-assembled units only.

Package Quantity: 1


Shape	No. of Positions	Contact Configuration	Contact E	Block	C Operator Position			Maintained		
	sitions	(Code)	Mounting Position	Contact	1	2		Bezel Color		
Knob Operator		1110	(1)	NO		•				
(Black)		1NO (10)	(2)	—	Dur	nmy		_	CW <sup>①</sup> S-2P10	—
<b>100</b>	°06	(10)	(3)	—	Dur	nmy		-		
		1NO-1NC	(1)	NO		•		1: Black		
	2-position	(11)	(2)	—	Dur	nmy		4: Metallic	CW <sup>①</sup> S-2P11	—
	ition		(3)	NC	•	-		-		
	_	2N0	(1)	NO		•		_	00000	
		(20)	(2)	NO	Dur	nmy		-	CW <sup>①</sup> S-2P20	—
(Metallic)			(3)	NU		•				
	No. of Positions	Contact Configuration (Code)	Contact Block		Operator Position		sition	① Bezel Color		Spring return two-way $1 \rightarrow 1^{-2}$
	tions		Mounting Position	Contact	1	0	2	]		$\bigvee$
			(1)	NO	•					
		2N0 (20)	(2)	—		Dummy	/		CW <sup>①</sup> S-3P20	CW1S-33P20
	45°	(20)	(3)	NO			•			
	5° 3	2NO-1NC	(1)	NO	•			1: Black		
	-pos	(21)	(2)	NO	•		•	4: Metallic	CW <sup>①</sup> S-3P21	—
	3-position	(= . ,	(3)	NC				-		
	⊐	2NO-1NC	(1)	NO	•			_		
		(21N1)	(2)	NC		•		-	-	CW1S-33P21N1
		. ,	(3)	NO				1		


 $\bullet$  Specify a bezel color in place of in the part no.

• Selector switches with 1 contact block contain 2 dummy blocks. Selector switches with 2 contact blocks contain 1 dummy block. Note: Turn the operator to each position accurately.

• For other contact configuration or operation, select from sub-assembled units (page 19 to 21).

# **Contact Block Mounting Position**






When ordering, specify the sub-assembled ordering no. See page 18 for available assembled products. Sub-Assembled

+







# 90° 2-position

10	2-positior	ו						Sub-Assembled	Ordering No.	l	Package Quantity:
		<re< th=""><th>eference&gt; A</th><th colspan="4">erence&gt; Assembled Part No.</th><th>Operator</th><th>Unit Ordering No.</th><th colspan="2">Contact Unit</th></re<>	eference> A	erence> Assembled Part No.				Operator	Unit Ordering No.	Contact Unit	
N		Conta	Contact Block			ition	Operator position code		Operator position code		Part No.
No. of Positions	Contact Configuration (Code)	Mounting		1	2		Maintained 1 2	Name / Shape	Maintained 1 2	Contact Configuration (Code)	(Ordering No.)
ons		Position			Ø		<reference> Assembled Part No.</reference>		Part No. (Ordering No.)	()	
	1110	(1)	NO					Knob Operator		1110	
	1NO (10)	(2)	—	Du	nmy		CW1S-23P10	(Black)		1NO (10)	CW-CNP10
	(10)	(3)			nmy					(10)	
	1NC	(1)		-	nmy					1NC	
	(01)	(2)		Du	nmy		CW10S-23901			(01)	CW-CNP01
	(01)	(3)	NC	•						(01)	
	1NO-1NC	(1)	NO							1NO-1NC	
	(11)	(2)			nmy		CW1S-23P11	(Metallic)		(11)	CW-CNP11
	2N0 (20)	(3)	NC	•						(,	
		(1)	NO					1		2N0	
		(2)		Du	nmy		CW1S-23P20			(20)	CW-CNP20
	( - /	(3)	NO								
	2NC	(1)	NC	•						2NC	
	(02) 2NO-1NC	(2)	-	-	nmy		CW(1)S-2(3)P02	Lever operator	CW①S-2③-PS	(02)	CW-CNP02
		(3)	NC	•				(Black)			
		(1)	NO		•			-		2N0-1NC	0.00
90		(2)	NO		•		CW1S-23P21			(21)	CW-CNP21
90° 2-position		(3)	NC	•							
pos	1N0-2NC	(1)	NO		•					1NO-2NC	OW OND 10
ition	(12)	(2)	NC NC	•			CW1S-23P12	( <b>M</b> - + - 11 - )		(12)	CW-CNP12
		(3)	NO	-	•			(Metallic)			
	3N0	(1) (2)	NO	-	•		CW1S-23P30			2010 (20)	CW-CNP30
	(30)	(3)	NO	+	•		GWU3-2@F30			3NO (30)	GW-GW-30
		(1)	NC	•							
	3NC	(1)	NC	•			CW1S-23P03			3NC (03)	CW-CNP03
	(03)	(3)	NC	•			0103-2@103			3NG (03)	011 03
				-	•						
		(1)									
	2N0-2NC	(2)			nmy		CW(1)S-2(3)P22			2N0-2NC	CW-CNP22
	(22)	(=)	NONC NO		•		01100 20122			(22)	on on LL
		(3)									
			NO	-	•						
		(1)	2N0 N0		•						
	4N0	(2)		-	nmy		CW1S-23P40			4N0	CW-CNP40
	(40)		2NO NO	_	•					(40)	
		(3)	2N0 N0		•						

Specify a bezel color in place of ① in the part no. • Specify an operator style code in place of ③ in the part no.

<code>Bezel color code</code>

③Operator style code

Code	Color	Code	Shape
1	Black	Blank	Knob
4	Metallic	L	Lever


Part No. (Ordering No.)/ mounting positions of contact units: page 30.

 For part no. other than maintained position, see Part No. Example on page 21.

• For contact block mounting position, see page 30.

• White indicator on black body


Note: Turn the operator to each position accurately.



		(2)	_	Dummy	CW1S-33P11N1
	(11N1)	(3)	NO		
	110 110	(1)	NO		
	1NO-1NC (11N2)	(2)	NC		CW1S-33P11N2
	(11NZ)	(3)	_	Dummy	
	110 110	(1)	_	Dummy	
	1NO-1NC	(2)	NC		CW1S-33P11N3
	(11N3)	(3)	NO		
	110 110	(1)	_	Dummy	
	1NO-1NC	(2)	NO	• •	CW1S-33P11N4
	(11N4)	(3)	NC		
	010	(1)	NO		
	2N0	(2)	_	Dummy	CW1S-33P20
	(20)	(3)	NO		
	010	(1)	_	Dummy	
45°	45° 3-position	(2)	NO	• •	CW1S-33P20N1
မု		(3)	NO		
soc	010	(1)	NC		
tion	Sition 2NC (02)	(2)	_	Dummy	CW1S-33P02
		(3)	NC		
		(1)	_	Dummy	
	2NC	(2)	NC		CW1S-33P02N1
	(02N1)	(3)	NC		
	010 110	(1)	NO		
	2NO-1NC	(2)	NO	• •	CW1S-33P21
	(21)	(3)	NC		
	010 410	(1)	NO		
	2NO-1NC	(2)	NC		CW1S-33P21N1
	(21N1)	(3)	NO		
	1110 0110	(1)	NO	•	
	1NO-2NC	(2)	NC		CW1S-33P12
	(12)	(3)	NC		
	110 010	(1)	NC		
	1NO-2NC (12N1)	(2)	NO	• •	CW1S-33P12N1
		(3)	NC		
	0110	(1)	NO	•	
	3N0	(2)	NO	• •	CW1S-33P30
	(30)	(3)	NO		
• Spec	ify a bezel co	lor in pla	ace of ①	in the part no.	

• Specify a bezer color in place of  $\oplus$  in the part no.

 $\bullet$  Specify an operator style code in place of  $\ensuremath{\textcircled{3}}$  in the part no.



③Operator style code							
Code	Shape						
Blank	Knob						
L	Lever						

For Part No. other than maintained position, see Part No. Example on page 21.

1NO-1NC

(11N4)

2N0

(20)

2N0

(20N1)

2NC

(02)

2NC

(02N1)

2NO-1NC

(21) 2NO-1NC

(21N1)

1N0-2NC

(12)

1NO-2NC

(12N1)

3N0

CW-CNP11N4

CW-CNP20

CW-CNP20N1

CW-CNP02

CW-CNP02N1

CW-CNP21

CW-CNP21N1

CW-CNP12

CW-CNP12N1

CW-CNP30

• For contact block mounting position, see page 30.

CW1S-33-PS

• White indicator on black body

Lever operator

(Black)

(Metallic)


Note: Turn the operator to each position accurately.

Part No. (Ordering No.)/ mounting positions of contact units: page 30.

Sub-Assembled Ordering No.

# Selector Switches (Knob / Lever Operator) 3-position

### 45° 3-position




• Specify a bezel color in place of ① in the part no.

Specify an operator style code in place of ③ in the part no.

①Bezel co	lor code	30perator s	style code
Code	Color	Code	Shape
1	Black	Blank	Knob
4	Metallic	L	Lever

# Part No. Example / Part No. Development

Assembled and sub-assembled unit



#### Operator Unit Ordering No. Contact Unit Operator position code Part No. (Ordering No.) Contact Maintained Name / Shape Configuration (Code) Part No. (Ordering No.) Knob Operator 3NC (Black) CW-CNP03 (03) 2NO-2NC (Metallic) CW-CNP22 (22)

Package Quantity: 1

• For Part No. other than maintained position, see Part No. Example below.

(1)

For contact block mounting position, see page 30.

CW1S-33-PS

· White indicator on black body

Lever operator

(Black)

(Metallic)

Note: Turn the operator to each position accurately.

# **Contact Block Mounting Position**

4N0

(40)

2NO-2NC

(22N2)

CW-CNP40


CW-CNP22N2



# Selector Switches (Knob / Lever Operator) Dimensions


All dimensions in mm

# **Knob Operator**




Locking Ring Rubber Gasket

# Lever Operator



4-contacts

4-contacts



• See page 9 for mounting hole layout.

**Key Selector Switches** 

Assembled



									Package Quantity: 1	
Shape	No. of Positions	Contact Configuration	Contact Block		Operator Position		sition	① Bezel Color	Maintained	
	ns f	(Code)	Mounting Position	Contact	1	2				
CW1K			(1)	NO		•				
Black		1NO (10)	(2)	—	Dun	nmy			CW <sup>①</sup> K-2AP10	
-		(1-7)	(3)	—	Dun	nmy				
			(1)	NO		•			CW①K-2③P11	
100	90	90° (11) 2-position 2N0	(2)		Dun	nmy				
	° 2-p		(3)	NC	•			1: Black		
-	ositi	ositi	ositio	(1)	NO		•		4: Metallic	
Metallic	n	2N0 (20)	(2)	—	Dun	nmy			CW1K-23P20	
			(3)	NO		•				
		2NO-1NC	(1)	NO		•				
			2NU-TNC (21)	(2)	NO		•			CW1K-23P21
			(3)	NC	•					
	No. of Positions	Contact Configuration (Code)	Configuration		ator Position ① Bezel Color			Maintained		
	S	(0000)	Mounting Position	Contact	1	0	2			
	ω		(1)	NO	•					
	45° 3-position	2NO-1NC (21)	(2)	NO	•		•	1: Black 4: Metallic	CW1K-33P21	
	on		(3)	NC						

• For contact block mounting position, see the figure on the right.

• Two keys are supplied. Key cylinder material: Metal

• Key selector switches with 1 contact block contain 2 dummy blocks. Key selector switches with 2 contact blocks contain 1 dummy block.

 $\bullet$  Specify a bezel color in place of in the part no.

 $\bullet$  Specify a key removal position in place of 3 in the part no.

## **3 Key removal position**

#### 90° 2-position

Key Retained Position (Cam code: blank)					
A: Key removable in all B: Key removable at left					
positions					

• 12: Key retained position 22: Key retained position


#### 45° 3-position


Key Retained Position					
A: Key removable in all	B: Key removable at left /	H: Key removable at right			
positions	center	0 0 2			

• (1)(2): Key retained position (1)(2): Key retained position Note: The key cannot be removed in a spring return position. • Besides the standard key (key number 0H), six other keys are also available. See page 27 for details.

• For other contact configuration or operation, select from subassembled units (P24 to 26).

# **Contact Block Mounting Position**





• Two keys are supplied. Key cylinder material: Metal

• For part no. other than maintained position, see Part No. Example on page 27.

 $\bullet$  Specify a bezel color in place of in the part no.


 $\bullet$  Specify a desired key removal position in place of  $(\ensuremath{\mathfrak{I}})$  in the part no.

• Specify a key number in place of (5) in the part no.

See page 27 Part No. Example for details.

• On the spring-returned types, the key can be released only from the maintained position. On the maintained types, the key can be released from every position.

Key retained positions are also available. See page 27 for details.



Two keys are supplied. Key cylinder material: Metal
For part no. other than maintained position, see Part No. Example on page 27.

• For part no. other than maintained position, see Fart No. Example on p

 $\bullet$  Specify a bezel color in place of in the part no.

- Specify a desired key removal position in place of (3) in the part no.

• Specify a key number in place of (5) in the part no.

See page 27 Part No. Example for details.


 On the spring-returned types, the key can be released only from the maintained position. On the maintained types, the key can be released from every position. Key retained positions are also available. See page 27 for details.

Part No. (Ordering No.)/ mounting positions of contact units: page 30.

#### **Key Selector Switches**

#### Sub-Assembled When ordering, specify the sub-assembled ordering no. See page 23 for available assembled products.

## 45° 3-position



every position.

• Two keys are supplied. Key cylinder material: Metal

. For part no. other than maintained position, see Part No. Example on page 27.

• Specify a bezel color in place of ① in the part no.

- $\bullet$  Specify a desired key removal position in place of  $\ensuremath{\textcircled{3}}$  in the part no.
- Specify a key number in place of (5) in the part no.
- See page 27 Part No. Example for details.


### **Contact Block Mounting Position**



. On the spring-returned types, the key can be released only from the maintained position. On the maintained types, the key can be released from

Key retained positions are also available. See page 27 for details.

Part No. (Ordering No.)/ mounting positions of contact units: page 30.





IDEC 27

# **Key Selector Switches Dimensions**


# **Key Removal Position 2-position**








# **Key Removal Position 3-position**




Key

• Reversible (OH to 2H)



• Non-reversible (3H to 6H)



• See page 9 for mounting hole layout.

# Nameplates

	When ordering, specify the Ordering No.					
Description		Material	Part No.(Ordering No.)	Package	Dimensions (mm)	
	Legend	Matorial	Tart No.(ordoning No.)	Quantity		
CWAM					Marking plate HWNP is necessary.	
					Degree of protection: IP65	
					<ul> <li>Do not remove the gasket on the operator.</li> </ul>	
	Order marking plate (HWNP) separately.	Plastic (black)	CWAM	1		

Note: Cannot be used with HW/FB series control box types.

# **Making Plate**

When ordering, specify the Ordering No.

Description	Material	Part No.	Ordering No.	Package Quantity	Dimensions (mm)
	Aluminum		HWNP-	1	White legend on black background.     Engraving area: W25, H7
Image: HWNP-35	(black)	HWNP-□	HWNP-□PN10	10	÷ <u>27</u> 

 $\bullet$  Specify a legend code in place of  $\Box$  in the Ordering No.


#### Legends

Code	Legend	Code	Legend
0	(blank)	4	STOP
1	ON	31	OFF-ON
2	0FF	35	HAND-AUTO
3	START	53	HAND-OFF-AUTO

# Sub-Assembled

Package Quantity: 1

#### Contact Unit Part No. / Contact Table



(2) (3)

Contact Configuration (Code)	Part No. (Ordering No.)	Mounting Position	Contact
		(1)	1N0
1NO (10)	CW-CNP10	(2)	Dummy
(10)		(3)	Dummy
		(1)	Dummy
1NC (01)	CW-CNP01	(2)	Dummy
(01)		(3)	1NC
		(1)	1N0
1N01NC	CW-CNP11	(2)	Dummy
(11)		(3)	1NC
		(1)	1NC
1N01NC	CW-CNP11N1	(2)	Dummy
(11N1)		(3)	1N0
	CW-CNP11N2	(1)	1N0
1N01NC		(2)	1NC
(11N2)		(3)	Dummy
	CW-CNP11N3	(1)	Dummy
1N01NC		(2)	1NC
(11N3)		(3)	1N0
	CW-CNP11N4	(1)	Dummy
1N01NC		(2)	1N0
(11N4)		(3)	1NC
		(1)	1N0
2N0	CW-CNP20	(2)	Dummy
(20)		(3)	1N0
		(1)	Dummy
2N0	CW-CNP20N1	(2)	1N0
(20N1)		(3)	1N0
		(1)	1NC
2NC	CW-CNP02	(2)	Dummy
(02)		(3)	1NC
		(1)	Dummy
2NC	CW-CNP02N1	(2)	1NC
(02N1)		(3)	1NC

Contact Configuration (Code)	Part No. (Ordering No.)	Mounting Position	Contact
010110		(1)	1N0
2N01NC (21)	CW-CNP21	(2)	1N0
(= ')		(3)	1NC
2N01NC		(1)	1N0
(21N1)	CW-CNP21N1	(2)	1NC
(2.111)		(3)	1N0
1N02NC		(1)	1NO
(12)	CW-CNP12	(2)	1NC
		(3)	1NC
3NO (30)	CW-CNP30	(1)	1NO
		(2)	1NO
(00)		(3)	1NO
3NC	CW-CNP03	(1)	1NC
(03)		(2)	1NC
(00)		(3)	1NC
2N02NC		(1)	1NO-1NC
(22)	CW-CNP22	(2)	Dummy
(==)		(3)	1NO-1NC
2N02NC		(1)	2NC
(22N2)	CW-CNP22N2	(2)	Dummy
()		(3)	2N0
4N0		(1)	2N0
4NO (40)	CW-CNP40	(2)	Dummy
(10)		(3)	2N0

Contact unit includes a contact block, dummy block, and connecting unit.

Note: Specify the same contact configuration as the reference assembled part no.

# Sub-Assembled

Illuminated Contact Unit Part No. / Contact Table Package Quantity: 1

Contact Configuration (Code)	Rated Operating Voltage	Part No. (Ordering No.)	Mounting Position	Contact		
1110	6V AC/DC	CW-CNP10Q2	(1)	1N0		
1NO (10)	12V AC/DC	CW-CNP10Q3	(2)	LED unit		
(10)	24V AC/DC	CW-CNP10Q4	(3)	Dummy		
1NC	6V AC/DC	CW-CNP01Q2	(1)	Dummy		
(01)	12V AC/DC	CW-CNP01Q3	(2)	LED unit		
(01)	24V AC/DC	CW-CNP01Q4	(3)	1NC		
1110 1110	6V AC/DC	CW-CNP11Q2	(1)	1N0		
1NO-1NC (11)	12V AC/DC	CW-CNP11Q3	(2)	LED unit		
(11)	24V AC/DC	CW-CNP11Q4	(3)	1NC		
	6V AC/DC	CW-CNP20Q2	(1)	1N0		
2N0 (20)	12V AC/DC	CW-CNP20Q3	(2)	LED unit		
(20)	24V AC/DC	CW-CNP20Q4	(3)	1N0		
0110	6V AC/DC	CW-CNP02Q2	(1)	1NC		
2NC (02)	12V AC/DC	CW-CNP02Q3	(2)	LED unit		
(02)	24V AC/DC	CW-CNP02Q4	(3)	1NC		

• Illuminated contact unit includes a contact block, LED unit, dummy block, and connecting unit.

Contact Unit for Pilo	Package Quantity: 1		
	(1) (2) (3)	5	
Rated Operating Voltage (Code)	Part No. (Ordering No.)	Mounting Position	Contact

· · · ·				
6V (Q2)	CW-CNPQ2	(1)	Dummy	
12V (Q3)	CW-CNPQ3	(2)	LED unit	
24V (Q4)	CW-CNPQ4	(3)	Dummy	
- Contract unit for allot light includes and LED unit two dummy blacks and and				

 Contact unit for pilot light includes one LED unit, two dummy blocks, and one connecting unit.

Note: Specify the same contact configuration as the reference assembled part no.

# Accessories

Shape	Material	Part No.	Part No. (Ordering No.)	Package Quantity	Remarks	
Locking Ring Wrench	Metal (Brass)	MW9Z-T1	MW9Z-T1	1	Used to tighten the locking ring when installing the CW series control unit in a panel cut-out.     Weight: Approx 150 g	
Mounting Hole Plug	Polyamide (black)	LW9Z-BP1	LW9Z-BP1	1	<ul> <li>Used to plug an unnecessary ø22.3 mm hole in the panel.</li> <li>Degree of protection: IP65</li> <li>Panel thickness: 0.8 to 6.0 mm</li> </ul>	
Rubber Boot The second	Rubber (Transparent silicon	CW9Z-D11	CW9Z-D11	1	<ul> <li>Degree of protection: IP66/67 UL Type 4X</li> <li>Panel thickness: 0.8 to 3.2 mm</li> <li>Use with round flush illuminated pushbuttons/pushbuttons.</li> </ul>	
<sup>(2)</sup> <sup>(2)</sup> For round extended	rubber)	CW9Z-D12	CW9Z-D12	1	<ul> <li>Degree of protection: IP66/67 UL Type 4X</li> <li>Panel thickness: 0.8 to 3.2 mm</li> <li>Use with round extended illuminated pushbuttons/pushbuttons.</li> </ul>	

All dimensions in mm

All dimensions in mm

# Maintenance Parts (Used for replacement only. Do not use the maintenance parts to modify the CW series)

All dimensions in mm

Name / Shape	Material		Part No.	Part No. (Ordering No.)	Package Quantity	Remarks	
Contact Block	1NO contact Housing color: blue		HW-P10R	HW-P10R	5	Contact No.: 1st stage: 3-4	
	1NC contact Housing color: reddish purple		HW-P01	HW-P01	5	Contact No.: 1st stage: 1-2	Note:
Double contact block	2NO contact Housing color: blue		HW-PW2R0	HW-PW2R0	5	Contact No.: 1st stage: 13-14 2nd stage: 23-24	Switches with 1 contact block contain 2 dummy blocks. Switches with 2 contact blocks contain 1
	2NC contact Housing color: reddish purple		HW-PW02	HW-PW02	5	Contact No.: 1st stage: 11-12 2nd stage: 21-22	dummy blocks
(Image: HW-PW2RO)	1NO1NC contact Housing color: reddish purple / blue		HW-PW1R1	HW-PW1R1	5	Contact No.: 1st stage: 13-14 2nd stage: 21-22	
Connection unit	_		CW-CN	CW-CN	1	Connecting unit for Push-in termina	al
Dummy Block	Polyamide (black)		CW-DB	CW-DBPN05	5	_	
LED module	Rated	6V AC/DC	CW-PAQ2	CW-PAQ2	1	1 Current draw	AC: 16 mA DC: 12 mA
		12V AC/DC	CW-PAQ3	CW-PAQ3			AC: 7 mA DC: 6 mA
		24V AC/DC	CW-PAQ4	CW-PAQ4			AC: 6 mA DC: 6 mA

Name / Shape		Material	Part No.	Ordering No.	Package Quantity	Remarks	
Button ① ②	① Round flush	Polyarylate ø19.5 H3.5	CW9Z-B11*	CW9Z-B11*PN05	5	For maintained pushbuttons. Specify a button color code in place of * in	
	② Round extended	Polyarylate ø19.5 H6.2	CW9Z-B12*	CW9Z-B12*PN05	5	the Part No. B (black), G (green), R (red), Y (yellow), S (blue), W (white)	
Lens D 2	① Round flush	Polyarylate ø19.5 H3.5	CW9Z-L11*-K	CW9Z-L11 * -KPN05	5	For illuminated pushbuttons. Specify a button color code in place of * in the Part No. R (red), G (green), Y (yellow), A	
(2) Round extended		Polyarylate ø19.5 H6.2	CW9Z-L12*-K	CW9Z-L12*-KPN05	5	(amber), C (clear), S (blue) Note:If the illumination color is PW (pure white), use a C (clear) lens.	
Locking Ring		Polyamide (black)	CW9Z-LN	CW9Z-LNPN05	5	_	
Gasket	$\mathbf{>}$	Nitrile rubber	CW9Z-WM	CW9Z-WMPN10	10	Waterproof gasket between CW control unit bezel and the mounting panel.	
Spare Key Reversible		LA9Z-SK-0H		LA9Z-SK-0HPN02		Specify a key No. in place of □. OH: Standard key (reversible) 1H to 2H: Reversible key	
		(nickel-plated)	LA9Z-SK-□	LA9Z-SK-□PN02	2	<ul><li>3H to 6H: Non-reversible key</li><li>For dimensions, see page 28.</li></ul>	

### Safety Precautions

- Turn off the power to the CW series switches & pilot lights before starting installation, removal, wiring, maintenance, and inspection of the products. Failure to turn power off may cause electrical shocks or fire hazard.
- For wiring, use wires of a proper size to meet the voltage and current requirements. and the number of connectable wires (page 39).

#### Instructions

## **Notes for Operation**

 When using the CW series control units in a safety-related circuit of a control system, observe safety rules and regulations of each country concerning particular applications of the actual machines and facilities. Perform risk assessment before operation to ensure safety.


#### **Operating Conditions**

- In corrosive gas or high-temperature, high-humidity atmosphere, contact failure due to corrosion or color change or breakage of the housing may occur.
- Main parts of the CW series control units are made of plastic. Do not scratch the surface with a sharp object or apply excessive shocks or load, otherwise the control units may be damaged.
- In particular, keep the button, lens, and bezel from such damage, otherwise appearance and function may be impaired.
- Do not apply detergents, cutting oils, or chemicals which may impair the function and appearance of the CW series control units.


#### Installing the Contact Unit

- 1. Remove the contact block from the operator.
- 2. Remove the locking ring from the operator.
- 3. With the TOP marking of the operator facing upwards, align the antirotation projection on the operator with the recess in the mounting hole, insert the operator into the mounting hole. <u>TOP</u> When installing the nameplate, insert between the operator and the panel.
- 4. Tighten the locking ring from the rear of the panel.

#### **Pushbuttons and Illuminated Pushbuttons**



#### Selector and Key Selector Switches




Failure to tighten the terminal screws may cause overheating and fire.

- Avoid using in places mentioned below to maintain performance of the product.
  - -Exposed to direct sunlight
  - -Subject to corrosive or flammable gases

#### Removing and Installing the Contact Unit

- 1. To remove the contact block from the operator, push the yellow locking lever and turn it to the left.
- To install, align the TOP marking on the operator with the TOP marking on the contact block mounting adaptor, and turn the locking lever to the right.

2. Turn left



#### **Notes for Panel Mounting**

Locking ring wrench recommended torque Tighten the bezel to a tightening torque of 1.2 N·m

#### Locking ring wrench

Locking ring wrench (MW9Z-T1) can be used to tighten the bezel. Do not use pliers. Excessive tightening will damage the locking ring.



Locking ring wrench (MW9Z-T1)

#### **Mounting Hole**

- 1. Mounting hole dimensions are in compliance with IEC 60947-5-1.
- If the anti-rotation projection is removed from the bezel, CW series control units can be mounted in ø22.3 mm mounting holes. To remove the anti-rotation projection, remove the gasket and use cutting pliers to break the projection.

Also, make sure not to damages other parts of the operator.



# Removing and Installing Contact Blocks, Dummy Blocks and LED Unit

#### Removing

To remove the contact block, dummy block, and LED unit from the operator, insert a flat screwdriver under the latch and push down the screwdriver as shown below.




#### Installing

When installing the contact block or dummy block, make sure that it snaps on to the operator.

- Note 1) Make sure to attach a correctly assembled connection unit to the operator.
- Note 2) When attaching the contact block to the connection unit, make sure that the connection is detached from the operator.

If a contact block is installed with the operator attached to the connection unit, malfunction of the switch may occur.




#### **Test Point**

Note) Do not insert wires to the test points.

#### Single contact block


Note) When conducting a continuity test, make sure that the probes (ø2.0 maximum) of the tester are inserted vertically to the panel.



#### **Double contact block**

When conducting a continuity test on the first deck, make sure that probes (Ø2.0 maximum) of the tester are inserted in an angle of the contact block, in two places as shown below.

When conducting a continuity test on the second deck, make sure that probes (Ø2.0 maximum) of the tester are inserted vertically to the panel.



(2) Second deck test point

#### **Removing and Installing Lens and Buttons**

#### Pushbuttons (momentary)

Momentary pushbutton caps cannot be removed. Do not tamper with the pushbutton caps using a screwdriver or pliers, otherwise the pushbutton caps may be damaged.


#### Pushbuttons (maintained) / Illuminated Pushbuttons / Pilot Lights

To remove the button or lens from a pushbutton, illuminated pushbutton or pilot light, insert a flat screwdriver under the flange of the lens at 90° from the TOP marking and twist the screwdriver. Note) Insert the flat screwdriver by about an angle of 30°. Do not insert the

screwdriver too deeply and do not apply excessive force to the lens, otherwise the bezel surface may be damaged.


Screwdriver Insertion Direction






Screwdriver Insertion Angle






#### Installing the Lens

Turn the groove in the lens to the TOP marking on the operator housing. With the groove aligned with the ridge, press the lens in.



#### Marking

Marking plates are not available for CW series illuminated pushbuttons and pilot lights. Marking film can be inserted to indicate legends.




#### Nameplate / Marking Plate

Installing the marking plate on a nameplate Insert a marking plate tin the direction of the arrow ①, and press in as shown ②.




#### **Removing a Marking Plate**

Insert a flat screwdriver into the upper middle part of the marking plate and remove. When anti-rotation is not required, remove the projection from the nameplate using pliers.



Note: When using a nameplate, the mounting panel thickness is 2.6 mm maximum.




#### Installing the Rubber Boot

When using in places where the switches are subjected to water splash or an excessive amount of dust, make sure to use the optional rubber boot.

- 1. Remove the gasket from the operator, and mount the rubber boot to cover the bezel as shown in the below diagram (Do not use a washer).
- 2. Fit the rubber boot to the bezel of the operator as shown in the diagram of the completed operator below.

#### Notes

- Attach the rubber boot by making sure that the front round part (A) of the rubber boot is concentric with the lens and button.
   Otherwise the appearance may look different.
- Make sure that the rubber boot is properly fitted, otherwise, the waterproof and dustproof characteristics are not ensured.



Note: Install the rubber boot before mounting the unit to the panel.

#### **Key Selector Switches**

- To prevent malfunctions and damage, take the following precautions.
- Insert the key to the bottom before turning.
- Do not remove the key while turning.
- Besides the standard key (0H), six other keys are available. Use a key with a key that matches with the number on the key cylinder. However, for standard keys, the key number is engraved on the key but not on the key cylinder.
- Keys are available in two shapes. Key numbers 0H (standard), 1H, and 2H are reversible keys. Key numbers 3H, 4H, 5H, and 6H are non-reversible keys. Make sure of correct insertion direction.

#### **Maintained Switches**

Do not replace the button/lens while the operator is latched. Otherwise the internal structure will be damaged.

#### **Selector Switches**

Turn the selector operator or key securely to each position.

#### **Applicable Wire**

When wiring, use the applicable wires shown below.

#### Applicable Wire and Specifications

Applicable Wire (*1)	0.25 to 1.5mm <sup>2</sup> (AWG16 to 24)
Wire Strip Length (*2)	8 ± 1mm (*3)

\*1) For applicable wires confirmed by IDEC, see website.

- \*2) For details on ferrules, see "Wire Size and Recommended Ferrules" table below.
- \*3) Strip the sheath of the wire 8±1mm from the end.



Note: Make sure that the stranded wires do not loosen when using wiring without ferrules.

#### Wire Size and Recommended Ferrules

#### Ferrules without insulated covers

Applicable Wire (Stranded Wire)		Wire Strip Length	Weidmüller Recommended Part No.	
AWG	mm <sup>2</sup>	Longui	Tart No.	
24	0.25	5 to 6mm	H0.25/5	
20	0.50	10 to 11mm	H0.5/10	
18	0.75	10 to 11mm	H0.75/10	
18	1.00	10 to 11mm	H1.0/10	
16	1.50	10 to 11mm	H1.5/10	

Note) Above ferrules cannot be purchased from IDEC.

#### Ferrules with insulated covers

	ble Wire ed Wire)	Wire Strip Length	IDEC Part No.	
AWG	mm <sup>2</sup>	Lengui		
24	0.25	10 to 11mm	S3TL-H025-12WJ	
22	0.34	10 to 11mm	S3TL-H034-12WT	
20	0.50	10 to 11mm	S3TL-H05-14WA	
18	0.75	10 to 11mm	S3TL-H075-14WW	
18	1.00	10 to 11mm	S3TL-H10-14WY	
16	1.50	10 to 11mm	S3TL-H15-14WR	

#### **Recommended Crimping Tool (Optional)**

Item	Weidmüller Recommended Part No.
Crimping tool	PZ 6 Roto L


Note 1) Note the crimping dimensions when using tools other than the recommended crimping tool. For details, see page 38.

Note 2) The above crimping tool cannot be purchased from IDEC.

#### **Recommended Screwdriver (Optional)**

	,
Item	IDEC Part No.
Flat blade	S3TL-D04-20-60
screwdriver	S3TL-D04-25-75


Note ) Use a flat blade screwdriver with a blade size of 0.4×2.5 mm.



#### Wiring Procedure


#### Connecting the wire

- 1) Stranded wires with ferrules or solid wire
- Insert the wire to the back of the wire port.
- ② After wiring, tug lightly to make sure that the wire is properly connected.




#### 2) Stranded wire

- ① While pressing the pusher using a flat blade screwdriver (recommended optional screwdriver: S3TL-D04-20-60 or S3TL-D04-25-75), insert the wire fully in the wiring port. Wire is connected when the pusher is released.
- ② After wiring, tug lightly to make sure that the wire is properly connected.



#### **Crimping of Ferrules and Wiring**


- Choose an appropriate ferrule for the wire.
- Cut the wire carefully to get a flat end.
- Make sure that ferrule sleeve is completely filled by the conductor. Depending on the cross section, the conductor should protrude approx. 0 to 1 mm from the ferrule sleeve.



• When crimping, refer to the instructions of the crimping tool.

#### Faults which can occur during crimping:

- Cracks along the sides and die impressions
- · Splitting of the ferrules
- Asymmetrical crimping shape
- Extreme burrs formed along the sides
- · Ferrule not filled by conductor
- Single conductors pushed back by protruding from the insulated cover
- Single conductors squeezed off
- Insulated cover damaged by the crimping jaw
- · Conductor insulation not pushed into the insulated cover
- Ferrule bent longitudinally after crimping



Formation of cracks at the sides. Slides split open

 Formation of cracks at the impressions of the crimping jaw

Asymmetrical crimping shape. Burr formation on one side

Asymmetrical crimping shape. Burr formation on one side

Single conductor squeezed off

Single conductor pushed back

#### Crimping dimensions: W2.4×H1.9 mm

Maximum connectable crimping size is  $W2.4 \times H1.9$ . Make sure that the ferrule size will be smaller than this dimension.

(Recommended crimping tool: PZ 6 Roto (optional) Weidmüller)

Max. 2.4mm


J.

Note 1) If a tool other than the recommended crimping tool is used, the ferrule may not be crimped to the appropriate size and the clamp or spring inside the contact block may be deformed and may not operate normally.

Note 2) Pin crimp terminals cannot be used.

## **Removing the Wire**

When removing the wire, push the pusher using a flat blade screwdriver (recommended optional screwdriver: S3TL-D04-20-60, see page 33) and pull wire out in the direction of the arrow.



<Notes>

- Operate the pusher with a force of 20N. Do not press excessively. Otherwise, the switch may be damaged.
- Do not pull the wire out without depressing the pusher. When pulling the wire, be sure to pull in a straight direction. Otherwise, the socket may be damaged.

## **Number of Connectable Wires**

Unit		No. of connectable wires	
	Solid wire	0.25 to 1.5mm <sup>2</sup> (AWG16 to 24)	
HW-P	Stranded wire	0.25 to 1.5mm <sup>2</sup> (AWG16 to 24)	
Contact block LED unit	Ferrule	Without insulated cover         0.25mm²       :conductor length 5 to 10mm         0.5 to 1.0mm²       :conductor length 6 to 10mm         1.5mm²       :conductor length 8 to 10mm         With insulated cover       0.25 to1.0mm²:conductor length 6 to 10mm         1.5mm²       :conductor length 6 to 10mm         With insulated cover       0.25 to1.0mm²:conductor length 6 to 10mm         1.5mm²       :conductor length 8 to 10mm         Note) Pin terminals cannot be used       Note	2

Note) Only one wire can be inserted into one wire port.

# **Ordering Terms and Conditions**

Thank you for using IDEC Products.

By purchasing products listed in our catalogs, datasheets, and the like (hereinafter referred to as "Catalogs") you agree to be bound by these terms and conditions. Please read and agree to the terms and conditions before placing your order.

#### 1. Notes on contents of Catalogs

(1) Rated values, performance values, and specification values of IDEC products listed in this Catalog are values acquired under respective conditions in independent testing, and do not guarantee values gained in combined conditions.

Also, durability varies depending on the usage environment and usage conditions

- (2) Reference data and reference values listed in Catalogs are for reference purposes only, and do not guarantee that the product will always operate appropriately in that range.
- (3) The specifications / appearance and accessories of IDEC products listed in Catalogs are subject to change or termination of sales without notice, for improvement or other reasons.
- (4) The content of Catalogs is subject to change without notice.

#### 2. Note on applications

- (1) If using IDEC products in combination with other products, confirm the applicable laws / regulations and standards. Also, confirm that IDEC products are compatible with your systems, machines, devices, and the like by using under the actual conditions. IDEC shall bear no liability whatsoever regarding the compatibility with IDEC products.
- (2) The usage examples and application examples listed in Catalogs are for reference purposes only. Therefore, when introducing a product, confirm the performance and safety of the instruments, devices, and the like before use. Furthermore, regarding these examples, IDEC does not grant license to use IDEC products to you, and IDEC offers no warranties regarding the ownership of intellectual property rights or non-infringement upon the intellectual property rights of third parties.
- (3) When using IDEC products, be cautious when implementing the following.
  - Use of IDEC products with sufficient allowance for rating and i. performance
  - ii. Safety design, including redundant design and malfunction prevention design that prevents other danger and damage even in the event that an **IDEC** product fails
  - Wiring and installation that ensures the IDEC product used in your iii. system, machine, device, or the like can perform and function according to its specifications
- (4) Continuing to use an IDEC product even after the performance has deteriorated can result in abnormal heat, smoke, fires, and the like due to insulation deterioration or the like. Perform periodic maintenance for IDEC products and the systems, machines, devices, and the like in which they are used.
- (5) IDEC products are developed and manufactured as general-purpose products for general industrial products. They are not intended for use in the following applications, and in the event that you use an IDEC product for these applications, unless otherwise agreed upon between you and IDEC, IDEC shall provide no guarantees whatsoever regarding IDEC products.
  - Use in applications that require a high degree of safety, including nuclear power control equipment, transportation equipment (railroads / airplanes / ships / vehicles / vehicle instruments, etc.), equipment for use in outer space, elevating equipment, medical instruments, safety devices, or any other equipment, instruments, or the like that could endanger life or human health
  - ii. Use in applications that require a high degree of reliability, such as provision systems for gas / waterworks / electricity, etc., systems that operate continuously for 24 hours, and settlement systems
  - iii. Use in applications where the product may be handled or used deviating from the specifications or conditions / environment listed in the Catalogs, such as equipment used outdoors or applications in environments subject to chemical pollution or electromagnetic interference If you would like to use IDEC products in the above applications, be sure to consult with an IDEC sales representative

#### 3. Inspections

We ask that you implement inspections for IDEC products you purchase without delay, as well as thoroughly keep in mind management/maintenance regarding handling of the product before and during the inspection.

#### 4. Warranty

(1) Warranty period

The warranty period for IDEC products shall be one (1) year after purchase or delivery to the specified location. However, this shall not apply in cases where there is a different specification in the Catalogs or there is another agreement in place between you and IDEC.

(2) Warranty scope

Should a failure occur in an IDEC product during the above warranty period for reasons attributable to IDEC, then IDEC shall replace or repair that product, free of charge, at the purchase location / delivery location of the product, or an IDEC service base. However, failures caused by the following reasons shall be deemed outside the scope of this warranty.

- The product was handled or used deviating from the conditions / i. environment listed in the Catalogs
- The failure was caused by reasons other than an IDEC product ii.
- Modification or repair was performed by a party other than IDEC iii.
- iv. The failure was caused by a software program of a party other than IDEC
- The product was used outside of its original purpose ٧.
- Replacement of maintenance parts, installation of accessories, or the like vi. was not performed properly in accordance with the user's manual and Cataloos
- vii. The failure could not have been predicted with the scientific and technical standards at the time when the product was shipped from IDEC.
- The failure was due to other causes not attributable to IDEC (including viii cases of force majeure such as natural disasters and other disasters) Furthermore, the warranty described here refers to a warranty on the IDEC product as a unit, and damages induced by the failure of an IDEC product are excluded from this warranty.

#### 5. Limitation of liability

The warranty listed in this Agreement is the full and complete warranty for IDEC products, and IDEC shall bear no liability whatsoever regarding special damages, indirect damages, incidental damages, or passive damages that occurred due to an IDFC product.

#### 6. Service scope

The prices of IDEC products do not include the cost of services, such as dispatching technicians. Therefore, separate fees are required in the following cases.

- (1) Instructions for installation / adjustment and accompaniment at test operation (including creating application software and testing operation, etc.)
- (2) Maintenance inspections, adjustments, and repairs
- (3) Technical instructions and technical training
- (4) Product tests or inspections specified by you


The above content assumes transactions and usage within your region. Please consult with an IDEC sales representative regarding transactions and usage outside of your region. Also, IDEC provides no guarantees whatsoever regarding IDEC products sold outside your region.

# IDEC CORPORATION

Head Office 6-64, Nishi-Miyahara-2-Chome, Yodogawa-ku, Osaka 532-0004, Japan

USA **IDEC** Corporation Singapore EMEA APEM SAS Thailand India

IDEC Izumi Asia Pte. Ltd. IDEC Asia (Thailand) Co. 1 td IDEC Controls India Private Ltd. China IDEC (Shanghai) Corporation IDEC Izumi (H.K.) Co., Ltd. Taiwan **IDEC** Taiwan Corporation



DEC

🖵 www.idec.com

Specifications and other descriptions in this brochure are subject to change without notice. Information in this brochure is current as of December, 2023. 2023 IDEC Corporation, All Rights Reserved.